

Air Fried Banana S'mores

Prep Time: 10 mins

Cook Time: 10 mins

Serve: 5

Ingredients

5-6 [Dole](#) Bobby Bananas

1/4 cup Mini Marshmallows

3 tbsp Chocolate chips

3 tbsp [Harraways](#) whole Oats

3 tbsp [FreshLife](#) Macadamia nuts, Roughly chopped

1 tbsp [Olivado](#) Extra Virgin Macadamia Nut Oil

[Philips Premium Smart XXL Air Fryer](#)

Method

1. In a small bowl combine oats, macadamia nuts and oil. Set aside.
2. Make a slit into the un-peeled bananas lengthwise along the inside of the curve. Open the banana slightly to form a pocket.
3. Fill each pocket with chocolate chips and marshmallows. Top with the oats & nuts mixture.
4. Place the bananas in the air fryer basket with the filling facing up. Cook at 170°C for 10 minutes, or until the banana is soft to the touch, the peel has blackened and the fillings have melted and toasted.